

PATIENT LIFT: FLYER XL with electrical opening legs



MADE FROM STEEL
WEIGHT CAPACITY: 300 kg
CLASS 1 MEDICAL DEVICE

CONFORM TO STANDARD NF EN ISO 10535: 2007

Contents

User Manual / Patient Lift: FLYER XL with electrical opening legs

Intended Purpose Scope of Delivery	1
Assembling Instructions	2-3
Patient Lifts Use	4-7
Motorisation Informations	8-9
Slings Use	10-13
Reuse Labelling	13-15
Preventive Maintenance & Security Controls	16-17
General Safety Guidelines	18
Technicals & Dimensionals Characteristics	19
Spare Parts	20
Cleaning & Maintenance	21
Motorisation Technicals Characteristics	22-23
Troubleshooting Guide	24
Warranty	25



Intended Purpose

The patient lift Flyer XL with electrical opening legs) is an active Class I medical product according to EU Council Directive 93/42/EC, Appendix IX. It can be universally used in the entire care sector (except potentially explosive areas).

Its use compensates for the disability or incapacity of the patient and makes the working conditions easier for the care personnel.

It is provided exclusively for transfer and transport of a patient with restricted mobility caused by illness or disability.

Moving the patient lift Flyer XL with electrical opening legs is only suitable for short distances inside the residence / sphere of activity of the patient and on one building level. It is only permitted to be used on a flat and level surface.

It is intended for short-time use without contact with injured skin and needs a suitable hoist sling for use. The patient is picked up in sitting position as standard; however a lying position is also possible when an Nausicaa lying transport clamp and lying transport sling are used. Even picking up a patient from the floor is possible.

The Flyer XL with electrical opening legs is suitable for a patient weight up to maximum 300 kg. The operation is performed by an instructed carer.

The Flyer XL with electrical opening legs is suitable for use at an ambient temperature from 0 °C to 40 °C, humidity of 20% to 80% and air pressure of 700 hPa to 1060 hPa in normally composed atmospheric air. It may be used in humid rooms such as bathrooms and toilets. Do not use this hoist under a running shower.

Syndromes such as osteogenesis imperfecta, osteoporosis or spinal column damage and mental aberration or epileptic attacks can be contraindications. The Flyer XL with electrical opening legs is only permitted to be used after careful consideration of the individual patient by the doctor and the care personnel.

Scope of Delivery

The Patient lift has already been inspected at the factory to ensure that it is free from defects and that nothing is missing. Nevertheless, please check the product immediately after receipt for any damage which may have occurred during transport.

Use the delivery note to check that all items are present and that the delivery is thus complete.

Вох	Contents	Units
	FLYER XL with electrical opening legs	1
FLYER XL with electrical opening legs	Baltery pack (removable)	1
	Handcontrol	1
	User Manual	1

Assembling Instructions

BEFORE USING YOUR PATIENT LIFT, IT IS NECESSARY TO CHECK:

- The wheels turn and roll normally.
- The rear wheels function correctly.
- There is no wear or deformation on the hooks.

WARNING:

- To preserve the inserts, do not overtighten.
- Assembly is done with the brakes locked.

Assembling Instructions

DIRECTIONS FOR USE:

- Your patient lift is designed to lift people, do not use it for other purposes.
- Check that the patient's weight does not exceed the maximum weight that can be raised by the patient lift.
- Do not force the controls and features of the patient lift, they are all easy to use and do not require strength.
- Operate the patient lift by pushing the handles, never by pushing the patient.
- The patient lift must be handled with care when a patient is transferred and at a speed appropriate to the situation.
- Operate the patient lift on flat and smooth surfaces. It is not recommended to be used on a slope of more than 5°. If you are forced to move on a ramp, it is recommended that a second person helps you. Do not use an electric patient lift in a shower.
- Do not recharge the batteries near a bath or shower.

Patient lifts allow patients to be transferred from a bed, chair, toilet, wheelchair or from the floor in an easy and efficient way.

In care environments, they offer to the caregiver the most appropriate solution for the basic tasks of patient handling: lifting and repositioning.





TRANSFERT FROM A BED



The mobile lifts are useful and efficient when a patient is dependent and therefore needs a caregiver to perform basic care.

Choosing the right device is essential as it has been demonstrated that the use of adapted equipment reduces the risk of injury, both for the patient and for the caregiver.

Using a patient lift requires a physical capacity assessment of the patient.

With our devices, caregivers can perform the following transfers:

- Patient transfer from a chair to a bed.
- Patient transfer from a bed to a chair.
- Patient transfer from the floor.



Parking brake

The parking brakes are one of the important safety elements of an stand-up lift. The rear castors are fitted with parking brakes which act directly on the wheels. To lock the castors, press the parking lever to the stop using your foot (Castor Locked). The stand-up lift can no longer be pushed in this setting. To release the castors, press the parking lever pointing upwards (Castor Released).

When locking the castors always insure that both castors are locked. If only one castor is locked on a sloping floor, the unlocked wheel will roll downhill around the locked wheel.

Depending on the slope of the surface, there is the danger that the stand-up lift will tip over sideways.

Castor Released



Castor Locked



- 1. If the patient is lying on his back, turn him so that he is facing away from you.
- 2. Fold the Nausicaa standard sling in half in the longitudinal direction.
- 3. Place the Nausicaa standard sling with the folded side on the back of the patient. In doing so, the Nausicaa logo and the labels must face downwards. Ensure that the bottom edge of the sling back part is on the coccyx and the top edge is on the shoulders of the patient.
- 4. Now roll the patient over the Nausicaa standard sling to the other side.
- 5. Now pull the folded half of the Nausicaa standard sling under the patient and place it properly.
- 6. Now turn the patient back onto his back.
- 7. The patient is lying correctly on the Nausicaa standard sling if his back is completely on the sling back part and the leg supports are next to the thighs.
- 8. Now raise the back part of the homecare bed until the patient is almost sitting upright.
- 9. Fold both the leg supports from the outside to the inside around the respective thighs of the patient.
- 10. Position your Nausicaa patient hoist with the Nausicaa standard transport clamp so that the Nausicaa standard transport clamp is at eye height in front of the patient. Ensure there is sufficient clearance between the face of the patient and the Nausicaa standard transport clamp.
- 11. Ensure before attaching to the clamp that both the shoulder loops as well as both the leg loops are at the same height.
- 12. Now hang both the shoulder loops in the outer hooks of the Nausicaa standard transport clamp.
- 13. Afterwards, hang both the leg loops crosswise on the inner hooks.
- 14. Raise the lifting arm of the Nausicaa patient hoist slightly until the leg and shoulder loops are tensioned. Now check whether the Nausicaa standard sling is attached correctly and comfortably.
- 15. You can now lift the patient. Use the manoeuvring handle located on the top edge of the sling back part for easier manoeuvring.





Observe the following safety instructions before every lifting / uprighting and conveying of the patient:

- The care personnel (user) must have the corresponding expert knowledge to select and use a suitable hoist sling.
- Check the permissibility of the combination of transport clamp and hoist sling based on Chapter 10 Accessories / Combinations before using the patient hoist.
- Verify the actual maximum load of the combination. In the case of differences between the maximum loads of patient hoist, transport clamp and sling, the lowest maximum load is always mandatory for you.
- Check the correct sling size and sling form in relation to the patient.
- Check the safe condition of the sling before every use. The sling must have neither tears in the material nor damaged seams.
- Check whether the correct loop combination has been attached. All loops have 3 different mounting levels: long medium short. Each loop pair (e.g. leg loops, shoulder loops) must only show the following mounting combination: long long, medium medium or short short.
- Check whether all loops are attached in the mounting hook.
- Lock the rollers/castors/wheels of the wheelchair, the homecare bed, the stretcher etc. in order to be able to raise and lower the patient safely. In doing so, leave the castors of the patient hoist unbraked.
- Arrange the patient transport to be as short as possible and never leave the patient hanging unsupervised in the hoist sling.
- Observe the patient during the transfer. Violent movements of the patient or holding on to objects during the transfer can result in hazards.
- Only lift the patient as high as is necessary.
- Keep the hoist slings away from intense heat or open flame; they are not flame retardant.



Prior to each use, it is important to check the status of the device: seams, state of the straps and of the fabric.

Any damage will either be repaired by NAUSICAA Medical, or will result in a disposal.

Motorisation Informations



Before use, check that the actuator and the handcontrol are correctly connected to the control unit (page 22)

Check the status of the control box and the battery





Check that the actuator is properly secured



2

Check that the battery is charged



Motorisation Informations



An assessment of the patient capacity is required before using a patient lift and more precisely the following parameters should be taken into account depending on the situation, such as the patient's physical handicap, pathology and morphology.

In order to choose the right sling, the caregiver shall take into account into account the three following factors:

- Patient height
- Patient waist size
- Patient thighs size


All our slings are Class 1 Medical Devices, provide sustainable solutions for reassuring transfers and are compatible with all patient lifts with a 2-point or 4-point spreader bar.

FABRICS

Depending on the slings model, we propose two types of fabric in polyester:

- Jersey: very easy to handle, provides an optimized and comfortable positioning.
- Net: ideal for bath and toilet, avoids maceration and easy to dry.

JERSEY



NET



IMPORTANT RECOMMANDATIONS

In order to get a maximum efficiency of these sort of product, it is necessary:

- to choose the appropriate size for the patient
- to get the best possible adjustment to the patient

These products must not be in direct contact with a wounded skin.

Read the instructions for use before using the sling.
Hang to the spreader bar the loop which are at the same level.
Do not change any adjustment while the patient is hanging in the sling.

Before lifting a patient, ensure that the sling is correctly hooked on the spreader bar.

Sling positionning

Check that loops are symmetrically attached to the shoulders and the legs





- Short ties at the shoulders level
- Long ties, crossed between the legs





Seated position:

- Medium ties at the shoulders
- Long ties at the shoulders level



Half-seated position:

- Medium ties at the shoulders level
- Long ties, uncrossed between the legs

For lying down transfers or lifting from the floor transfers, it is necessary to always use a sling with a headrest or to add a removable headrest to the sling.

For patients without head support, it is necessary to always use a sling with a headrest or to add a removable headrest to the sling.

CAUTION

Check that loops never slide off the hooks and check the make sure that the device (seams, state of the straps and of the fabric) is not damaged.

Check that the patient can not bump into something

Check that the combination sling / patient lifter maintains a good stability during the transfer



THIS MEDICAL DEVICE MUST BE SET UP BY A PROFESSIONAL OR THE USER MUST BE EDUCATED TO SET IT UP.

The type and size of the belt always depends on the patient's stature and the type of application. NAUSICAA Médical offers you a wide assortment of lifting straps adapted to your requirements.

Types of	Bed/chair transfer in a	Transfer with the sling		Bath, shower	Toilet and daily
Patient's transfers physical conditions	seated position	placed on the chair	Lifting from floor transfer	and pool transfer	change transfer
Simple amputee (short/long)	Comfort sling Fast adjustable comfort sling (without headrest) for 2-point spreader bar Universal eco sling (comfort)	Standard comfort hammock Universal eco hammock	Comfort sling (+ headrest) Comfort hammock without crossing (+ headrest) Universal eco hammock	Bath sling Fast adjustable bath sling (without headrest) - for 2-point spreader bar Fast adjustable eco sling (without headrest) - for 2-point spreader bar Universal eco sling (bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Double amputee (short/long)	Comfort hammock without crossing Standard comfort hammock Universal eco hammock	Standard comfort hammock Universal eco hammock	Comfort hammock without crossing (+ headrest) Standard comfort hammock Universal eco hammock	Bath hammock without crossing (+ headrest) Standard bath hammock Universal eco hammock	I
Convulsive hypertonic	Comfort hammock without crossing	I	Comfort hammock without crossing (+ headrest)	Bath hammock without crossing (+ headrest)	I
Person in a shell wheelchair	Backrest sling Quick toilet sling Backrest toilet sling	ı	Backrest sling	Backrest sling	Backrest sling
Bariatric patient	Bariatric sling	I	Bariatric sling	Bariatric sling	Bariatric sling
Agitated patient	Enveloping sling Ergonomic sling Universal eco hammock	Universal eco hammock	Enveloping sling Ergonomic sling Universal eco hammock	Fast adjustable bath sling for 2-point spreader bar Universal eco hammock	I
Postoperative phase of hip prosthesis replacement	Backrest toilet sling Quick toilet sling Comfort hammock without crossing	I	Comfort hammock without crossing	Quick toilet sling Bath hammock without crossing	Quick toilet sling
Patient with no head support	Comfort sling (+ headrest) Fast adjustable comfort sling Backrest sling	Standard comfort hammock Universal eco hammock	Comfort sling (+ headrest) Comfort hammock without crossing (+ headrest) Universal eco hammock	Bath sling (+ headrest) Fast adjustable bath sling - for 2-point spreader bar Universal eco hammock	I
Lack of muscle tone in the lower limbs	Comfort sling Fast adjustable comfort sling (without headrest) - for 2-point spreader bar Universal eco sling (comfort)	Standard comfort hammock Universal eco hammock	Comfort sling (+ head-rest) Comfort hammock without crossing (+ headrest) Universal eco hammock	Bath sling Fast adjustable bath sling (without headrest) - for 2-point spreader bar Fast adjustable eco sling (without headrest) - for 2-point spreader bar Universal eco sling (bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Lack of muscle tone at the bust and head level	Comfort sling Fast adjustable comfort sling (without headrest) - for 2-point spreader bar Universal eco sling (comfort)	Standard comfort hammock Universal eco hammock	Comfort sling (+ head- rest) Comfort hammock wit- hout crossing (+ headrest) Universal eco hammock	Bath sling Fast adjustable bath sling (without headrest) - for 2-point spreader bar Fast adjustable eco sling (without headrest) - for 2-point spreader bar Universal eco sling(bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Hemiplegia	Comfort sling Fast adjustable comfort sling (without headrest) - for 2-point spreader bar Universal eco sling (comfort)	Standard comfort hammock Universal eco hammock	Comfort sling (+ head-rest) Comfort hammock without crossing (+ headrest) Universal eco hammock	Bath sling Fast adjustable bath sling (without headrest) - for 2-point spreader bar Fast adjustable eco sling (without headrest) - for 2-point spreader bar Universal eco sling(bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Active paraplegia with muscle tone at the bust level	Backrest sling Universal eco sling (comfort)	1	Comfort sling (+ head- rest) Comfort hammock wit- hout crossing (+ headrest) Universal eco hammock	Bath sling Universal eco sling(bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Active paraplegia without muscle tone at the bust level	Comfort sling Fast adjustable comfort sling (without headrest) - for 2-point spreader bar Universal eco sling (comfort)	ı	Comfort sling (+ head- rest) Comfort hammock wit- hout crossing (+ headrest) Universal eco hammock	Bath sling Fast adjustable bath sling (without headrest) - for 2-point spreader bar Fast adjustable eco sling (without headrest) - for 2-point spreader bar Universal eco sling(bath)	Quick toilet sling Backrest toilet sling Universal eco toilet sling
Tetraplegia	Comfort sling (+ head-rest) Fast adjustable comfort sling Backrest sling Comfort sling C	Standard comfort hammock Universal eco hammock	Comfort sling (+ head- rest) Comfort hammock wit- hout crossing (+ headrest) Universal eco hammock	Bath sling (+ headrest) Fast adjustable bath sling for 2-point spreader bar Universal eco sling(bath)	I
Physical and psychical dependency	Enveloping sling Ergonomic sling Universal eco hammock	Universal eco hammock	Enveloping sling Ergonomic sling Universal eco hammock	Fast adjustable bath sling for 2-point spreader bar Universal eco sling(bath)	I

Weight / Size	1m50	1m55	1m60	1m65	1m70	1m75	1m80	1m85	1m90	+ 1m90
40 kg	S	S	S	S	S	S	М	М	М	М
45 kg	S	S	S	S	S	S	М	М	М	М
50 kg	S	S	S	S	S	S	М	М	М	М
55 kg	S	S	S	S	S	S	М	М	М	М
60 kg	М	М	М	S	S	S	М	М	М	М
65 kg	М	М	М	S	S	S	М	М	М	М
70 kg	М	М	М	М	М	М	М	М	М	M
75 kg	L	L	М	М	М	М	М	М	М	М
80 kg	L	L	L	L	М	М	М	М	М	М
85 kg	L	L	L	L	М	М	М	М	М	М
90 kg	L	L	L	L	L	L	М	М	М	М
95 kg	XL	XL	XL	XL	L	L	М	М	М	M
100 kg	XL	XL	XL	XL	L	L	L	L	L	L
110 kg	XL	XL	XL	XL	L	L	L	L	L	L
120 kg	XL	XL	XL	XL	XL	XL	L	L	L	L
130 kg	XL									
more then 130 kg	XL+									



Reuse

The patient hoist is suitable for reuse. Ensure that the patient hoist has been cleaned according to Chapter Care / Cleaning and serviced according to Chapter

Labelling

Labelling on the box



Labelling



SAFETY INSTRUCTIONS BEFORE EACH USE

NAUSICAA Medica



- · Check the perfect condition of the hoist sling.
- Check the perfect condition of the traction sling (EASYLEV, NAUSILEV).
- Verify the presence and conditions of safety devices: all axis and their constrained fixations (pins, clips and bolts) and the tightness of the screws (see user manual).

DO NOT USE THE DEVICE IN CASE OF ANY LACK OR BAD OVERALL STATE



NAUSICAA Médical (2)

POIDS MAXIMUM MAXIMUM WEIGHT MAXIMALE TRAGFÄHIGKEIT PESO MAXIMO PESO MASSIMO



300 kg

CENAUSICAA FRANCE Médical



4

- MAINTENANCE NAUSICAA
 A POORLY MAINTAINED BATTERY DETERIORATES
- Regularly recharge the battery at the maximum.
- Making small incomplete charges shortens the battery life.
- \bullet The battery should not be exposed to temperatures neither too low nor too high.
- The batteries status depends on the maintenance and therefore can not be under warranty.
- It is important to check the charger if the battery no longer works.





Labelling



Preventive Maintenance & Security Controls

Patient Lift: FLYER XL with electrical opening legs

Serial Number:

Control of security points (Frequency: depending on use, recommended every three months.

This is a sight control: any wear trace must lead to a replacement.)

		GOOD	WRONG	DATE OF CHANGE
1	Spreader bar fixation			
2	Actuator top fixation			
3	Mast top fixation			
4	Actuator bottom fixation			
5	Mast/Base assembly			
6	Mast/Base assembly 2			
7	Handle bar fixation			
8	Foot pedal fixation			
9	Wheels fixation			
10	Foot/base assembly			
11	Structure state			

Control of electrical functions (Frequency: depending on use, at least once a year) this control must be carried out when the hoist is loaded.

		GOOD	WRONG	DATE OF CHANGE
Α	Operation of the actuator			
В	Operation of the emergency system			
С	Batteries status (charge holding)			
D	Handcontrol status			

Inspection carried out on :	Inspection carried out by :	Date of the next inspection :

Preventive Maintenance & Security Controls

Control of security points (Frequency: depending on use, recommended every three months.

This is a sight control: any wear trace must lead to a replacement.)

Spreader bar fixation
Actuator top fixation
Mast top fixation
Actuator bottom fixation
Mast/Base assembly
Mast/Base assembly 2
Handle bar fixation
Foot pedal fixation
Wheels fixation

Foot/base assembly STRUCTURE STATE

THESE CONTROLS CAN BE CARRIED OUT WITHOUT LOAD



General Safety Guidelines

- 1. Use the Patient Lift only for its intended purpose, in accordance with the legislation for medical devices, the regulations for labor protection and accident prevention, as well as the generally recognized rules of technology.
- 2. Note that the Patient Lift is a medical device, therefore the user is required to comply with the directive on the use of medical devices.
- 3. The requirements for the electrical installation of the room or area where the Patient Lift is used must meet the current state of the technology.
- 4. Using the Patient Lift only after being trained for its handling.
- 5. Before using the device, please read the complete User Manual in order to avoid damage due to improper handling or exposure to risks. The User Manual contains important information and notes required for the Patient Lift use.
- 6. Use the Patient Lift in accordance with this User Manual only. Keep the User Manual for future reference in case of questions. Join this User Manual to the Patient Lift in case of change of ownership.
- 7. Before any use, it must be ascertained whether the Patient Lift and its accessories are in working order and in impeccable conditions.
- 8. Before using the Patient Lift with other medical and non-medical devices, check that the combination of these products is allowed and can be used together safely.
- 9. Assembly, commissioning, maintenance and repair of the Patient Lift should be entrusted only to specialists.
- 10. It is up to the user or operator to ensure (through adequate measures and instructions) that mechanical stress of the charging cord (through bending, tension, shear, crushing) is excluded during loading or cleaning of the part. This also applies to the electrical cables of other devices used with the Patient Lift.
- 11. Respect the activation duration and the maximum weight capacity. These values must not be exceeded, otherwise the Patient Lift safe operation is no longer guaranteed.
- 12. Do not expose the Patient Lift to direct sunlight or heat.
- 13. Ensure that no moisture enters the electrical system.
- 14. Avoid mechanical stress on electrical cords. Pull, bend or crush the cords may damage them.
- 15. Charge batteries in a well ventilated area.
- 16. Electromagnetic interferences can not be excluded from the Patient Lift and other devices. If there is a risk of such interference, the source of interference must be removed or the Patient Lift should not be used.
- 17. Disruptions caused by the use of portable communication devices can not be completely excluded. This is why a safe distance of at least 3 meters must be kept in order to ensure the functioning of the Patient Lift safely.
- 18. Do not leave unattended children stand near the Patient Lift.
- 19. The Patient Lift should not be used as soon as abnormal noises, damages or any other malfunctions occur. In this case, do not connect the wall charger to the Patient Lift and inform us.
- 20. If damaged or defective, the Patient Lift should not be used and should not be connected to the direct current. Inform the dealer to remedy the default or failure.

Technicals & Dimensionals Characteristics

- Frame made in steel
- Laser cutting and bending sheet metal, tubes and profiles
- Epoxy baked painting
- Ball bearing castors
- Total weight: 46 kg
- Weight of the heaviest part: 15 kg
- Weight capacity: 300 kg
- Lifespan: 8 years (except electrical parts)
- * SCP: Suspention central point

Spare Parts

PRAME NO. MAST FOR FLYER XI. PLEASE OF THE STATE OF THE		
FILES B. BASE FOR TYPE NE.	FLYER XL	
FIXE.BIT. INTERESTANCE OF CONTROL STREET ST. FIXE.PRESTANCE SPERADING ENTERTINES STREET STEET FOR FLYER XI. FIXE.PRESTANCE SPERADING ENTERTINES STREET STEET FOR FLYER XI. FIXE.PRESTANCE SPERADING ENTERTINES STREET STEET FOR FLYER XI. FIXE.PRESTANCE FIXE.PRESTANCE HANDLE FOR FOR FLYER XIX. FIXE.PRESTANCE F	FRAME	
INLEAD TO SPEADING SECRETICAL SYSTEM SET FOR EVER X. FIXLE-PELES SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PELES SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PELES SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PERCY SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PERCY SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PELES SPEADING MCCHANICAL SYSTEM SET FOR EVER X. FIXLE-PELES SPEADING SET SET FOR FOR EVER X. FIXLE-PELES SPEADING SET	FLXL-EMB	BASE FOR FLYER XL
INLEAFF LEC SPREADING BECTERICAL SYSTEMS SET OR FLYEN X FIRLS OF BERLANDER ON BERL	FLXL-BRL	LIFTING ARM FOR FLYER XL
FILLE-FE SPREADING MECHANICAL SYSTEM SET FOR EYER XI. FILL-BROCN MONTERAR FOR THE YERRY. MONTERAR FOR THE YERRY. FILL-BROCN MONTERAR FOR THE YERRY. MONTERAR FOR THE YERRY. FILL-BROCN MONTERAR FOR THE YERRY. FILL-BROCN FOR THE FOOT FOR EYERRY. A FORTS SPREADER BAR FOR PLYER XI. FILL-BROCN FOR THE FOOT FOR EYERRY. A FORTS SPREADER BAR FOR PLYER XI. FILL-BROCN MARKED SPREADER BAR FOR PLYER XI. MARKED SPREADER BAR FOR	FLXL-MT	MAST FOR FLYER XL
IRLE-DROK	FLXL-EP-ELEC	SPREADING ELECTRICAL SYSTEM SET FOR FLYER XL
ILLL.PROPK	FLXL-EP	SPREADING MECHANICAL SYSTEM SET FOR FLYER XL
FIX.P. PORT OF TOR FOR YESPART TAMAN FOR BLACK CASTORS [100mm our 75mm) FIX.P. POL. OF TOR POAL FOR FUYER XI FIX.P. POL. OF TOR FUYER XI MP. PURDIOLO BLACK TWIN CASTORS WITH IND BRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH IND BRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH IND BRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO BLACK TWIN CASTORS WITH THE DIBRAKE DUMMETER 100mm (ball bearing) MP. PURDIOLO MP. PUR	FLXL-GM	HANDLEBAR FOR FLYER XL
RILLE-POL FOR ELYER TA FOR POINTS SPREADER BAR FOR FLYER XL FUNE FLAT FUNE FLAT FOR POINTS SPREADER BAR FOR FLYER XL FUN FAIRHOUGH BLACK TWIN CASTORS UNIMITER 100mm (ball bearing) WF-RIPPOIDO BLACK TWIN CASTORS WITH RED BRACK DIMMETER 100mm (ball bearing) WF-BRACK BLACK TWIN CASTORS WITH RED BRACK DIMMETER 100mm (ball bearing) WF-BRACK BLUE ALTANTE STICKER PAINT WF-BRACK BLUE ALTANTE STICKER PAINT WF-SPRA BLUE ALTANTE STICKER PAINT WF-VEADORS ALUMINIUM GREY POOS STICKER PAINT WF-VEADORS FUN FLATANTE STICKER PAINT WF-VEADORS FUN FLATANTE STICKER PAINT WF-VEADORS WF-V	FLXL-PDRCN	RIGHT FOOT FOR FLYSPART MAXI FOR BLACK CASTORS (100mm ou 75mm)
FIX.FLE 44 4 POINTS SPEADER BAY FOR FYER'S XL. PRAMPT DO SPEADER BAY FOR FYER'S XL. PRE-RADIOD BLACK TWIN CASTORS DAMFERS (100m) (ball bearing) WP-RUPPOLOD BLACK TWIN CASTORS WITH FED BRAKE DAMFER (100m) (ball bearing) WP-RUPPOLOD BLACK TWIN CASTORS WITH FED BRAKE DAMFER (100m) (ball bearing) WP-RUPPOLOD BLUE AT A THE STEEL SHAPE TO THE STEEL SHAPE TO THE STEEL SHAPE TO THE	FLXL-PGRCN	LEFT FOOT FOR FLYSPART MAXI FOR BLACK CASTORS (100mm ou 75mm)
PS-ANDY PREADOBS BACK TWIN CASTORS DIAMETER 100mm (ball bearing) WP-RINDADIO BLACK TWIN CASTORS DIAMETER 100mm (ball bearing) WP-RINDADIO BLACK TWIN CASTORS WITH RED BRAKE DIAMETER 100mm (ball bearing) WP-BRAGOOS BLUE ATLANTE STICKER PAINT WP-WFABA BLUE ATLANTE STICKER B	FLXL-PDL	FOOT PEDAL FOR FLYER XL
WR-RINDIOD BLACK TWIN CASTORS WITH RED BRAKE DIAMETER 100mm (ball bearing) WR-PROROBO SET SPRAY PAINT ALUMINUM 3006° WR-BRAD BUL ATLANTE SPRAY PAINT WR-VEAD STEICH SPRAY PAINT WR-VEAD SELECT SPRAY PAINT WR-VEAD STEICH SPRAY PAINT WR-VEAD STEICH SPRAY PAINT BUL ATLANTE SPRAY PAINT WR-VEAD STEICH SPRAY PAINT STEICH STEICH S	FLXL-FL4	4 POINTS SPREADER BAR FOR FLYER XL
MP-RIFERDIOD BLACK TWIN CASTORS WITH RED BRAKE DIAMETER 100mm (ball bearing) MP-BRAGA000 GREY SPARY PAINT ALLIMINUM 2006* MP-BBBA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAADOOL ALLIMINUM GREY 9006 STICKER PAINT MP-WAADOOL STICKER PAINT MP-WAAD	F3-AXVF	SPREADER BAR VERTICAL AXIS
MP-RIFERDIOD BLACK TWIN CASTORS WITH RED BRAKE DIAMETER 100mm (ball bearing) MP-BRAGA000 GREY SPARY PAINT ALLIMINUM 2006* MP-BBBA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAA BLUE ATLANTE STICKER PAINT MP-WAADOOL ALLIMINUM GREY 9006 STICKER PAINT MP-WAADOOL STICKER PAINT MP-WAAD	WP-RJND100	BLACK TWIN CASTORS DIAMETER 100mm (ball bearing)
MR-BERGA0006 GREY SPARY PAINT "ALLIMINIUM 9005" WP-PBBA BLUE ATLANTE STICKER PAINT WP-VBA BLUE ATLANTE STICKER STICKER PAINT WP-VBA BLUE ATLANTE STICKER PAINT WP-VBA BLUE ATLAN	WP-RJNFRD100	
INC-BBBA BLUE ATLANTE STICKER PAINT WP-VGAGOGE ALUMINIUM GREY 9006 STICKER PAINT WP-VGAGOGE STICKER-CEC CONTROL FOR VGORD AS A FUNCTIONS REMOTE CONTROL FOR VGORDX 3 VS-TLCMS-CCC-ECP CONTROL BOAD FOR A FUNCTIONS REMOTE CONTROL FOR VGORDX 3 VS-TLCMS-CCC-ECP CONTROL BOAD FOR A FUNCTIONS REMOTE CONTROL FOR VGORDX 3 VS-TLCMS-CCC-ECP AND FOR REMOTE CONTROL HOOK STICKER-CECP ST		
NR-Y-BA BULE ATTAMTS TICKER PAINT WP-Y-GAGODG ALUMINUUM GREY 9006 STICKER PAINT WOTORIZATION YEOROGX **STICMS-SCEP** 4 FUNCTIONS REMOTE CONTROL FOR VEOROX 3 **STICMS-SCEP** CONTROL BOAD FOR A FUNCTIONS REMOTE CONTROL FOR VEOROX 3 **STICMS-SCEP** CONTROL BOAD FOR A FUNCTIONS REMOTE CONTROL FOR VEOROX 3 **STICMS-SCEP** CORD FOR A FUNCTIONS REMOTE CONTROL FOR VEOROX 3 **STICMS-SCEP** REMOTE CONTROL BOAD FOR A FUNCTIONS REMOTE CONTROL FOR VEOROX 3 **STICMS-SCEP** REMOTE CONTROL HOOK **STICMS-SCEP** REMOTE CONTROL HOOK **STICMS-SCEP** REMOTE ABLE FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOROX 3 **STICMS-SCEP** REMOTABLE BATTERY PACK (WITE 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING **STICMS-SCEP** STICMS-SCEP** REMOTABLE BATTERY PACK (WITE 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING **STICMS-SCEP** STICMS-SCEP** **STICMS-SCEP** STICMS-SCEP** STICMS-S		
MOTORIZATION VEGBOX 3 WS-TICMS-ECP 4 # FUNCTIONS REMOTE CONTROL FOR VEGBOX 3 WS-TICMS-ECP CONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEGBOX 3 WS-TICMS-ECP CORP FOR A FUNCTIONS REMOTE CONTROL FOR VEGBOX 3 WS-TICMS-ECP CORP FOR A FUNCTION SEMOTE CONTROL FOR VEGBOX 3 WS-MAIL MAGNET FOR REMOTE CONTROL WS-SECTI. # REMOTE CONTROL BOARD FOR A FUNCTION SEMOTE CONTROL FOR VEGBOX 3 WS-MAIL MAGNET FOR REMOTE CONTROL WS-SECTI. # REMOTE CONTROL BOARD #	WP-VBA	
MOTORIZATION VEGROX 3 VS-TICMS-CCCP ONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEGROX 3 VS-TICMS-CCC-ECP ONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEGROX 3 VS-TICMS-CCC-ECP ONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEGROX 3 VS-TICMS-CCC-ECP ONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEGROX 3 VS-TICMS-CRD-ECP SEARCH REMOTE CONTROL HOOK VS-EARL REMOTE CONTROL HOOK VS-EARL REMOTE CONTROL HOOK REMOTE CONTROL HOOK VS-TICMS-CC-FA REMOTE CONTROL HOOK REMOTE CONTROL HOOK REMOTE CONTROL HOOK VS-BCAM REMOVABLE BATTERY PACK (with 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING VS-BCAM REMOVABLE BATTERY PACK (with 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING VS-BCAM SECROPH OF A FUNCTION OF A FUN		
VS-TICM3-ECP 4 FUNCTIONS REMOTE CONTROL FOR VEOROX 3 VS-TICM3-CCC-ECP CONTROL BOARD FOR 4 FUNCTIONS REMOTE CONTROL FOR VEOROX 3 VS-TICM3-CCC-ECP CORD FOR 4 FUNCTIONS REMOTE CONTROL SY-SECRIT MAGNET FOR REMOTE CONTROL VS-TICM3-CCC-ECP ARMOTE CONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR VEOROX 3 VS-MANTL MAGNET FOR REMOTE CONTROL VS-TICM3-ECP-FA FRONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOROX 3 VS-ECRIT SECON ARMOTE CONTROL HOOK VS-TICM3-ECP-FA REMOTE CONTROL BOARD ARMOTE CONTROL 4 FUNCTIONS FOR VEOROX 3 VS-BCAM REMOVABLE BATTERY PACK (With 2 internal batteries SA/12/V) WITH LOAD DISPLAY AND BALANCING S-STO 21 INTERNAL BATTERIES SA/12/V VS-BCAM LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-KERT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KERT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KERC CONNECTION NIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP RUSS-S-20-1A INTERNAL DELAY FUSE S 2-20-1A 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAG-CCC-ECP CONTROL BOARD FOR VEOROX 3 4 FUNCTIONS VS-BCC3-ECC CONTROL BOARD WITH FUSE FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BCAG-CCC-ECP CONTROL BOARD WITH FUSE FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BCAG-CCC-ECP VS-BCAG-CCC-ECP DOWNER CORD VS-VEN-LD-C-EMB JOOON LIFTING ACTUATOR BASE SCREED BILITONS VS-VEN-LD-C-EMB JOOON LIFTING ACTUATOR BASE SCREED BILITONS FOR ACTUATOR (without the screed) VS-VEN-LD-C-EMB JOOON DIFFING ACTUATOR CORD (all models) VS-VEN-LD-C-EMB JOOON DIFFING BASE LEGS GREY ACTUATOR BASE SCREED JOON OPENING BASE LEGS GREY ACTUATOR BASE SCREED JOON OPENING BASE LEGS GREY ACTUATOR BASE SCREED JOON OPENING BASE LEGS GREY ACTUATOR BASE		
VS-TLCM3-CC-ECP CONTROL BOARD FOR A FUNCTIONS REMOTE CONTROL FOR YEOBOX 3 VS-MATL MAGNET FOR REMOTE CONTROL VS-CRTL REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-RCAM REMOVABLE BATTERY PACK (with 2 internal batteries \$A/12V) WITH LOAD DISPLAY AND BALANCING FS-BTZIN SET OF INTERNAL BATTERIES \$A/12V SET OF INTERNAL HITHIUM BATTERY SA/2V VS-BCAM-LU LITHIUM BATTERY PACK (with 10 internal batteries 5A/12V) WITH LOAD DISPLAY AND BALANCING FS-BTZIN SET OF INTERNAL BATTERIES \$A/12V VS-BCAM-LCR LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-LCR LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-LCR CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP NUS-52-02-000MA INTERNAL DELAY FUSE \$X20-200MA (bet of 5) NUS-52-02-000MA INTERNAL DELAY FUSE \$X20-120 A 50 V (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAC-CCC CONTROL BOAR FOR VEOROX 3 4 FUNCTIONS VS-BCAC-CCC CONTROL BOAR FOR VEOROX 3 4 FUNCTIONS VS-BCAC-CCC CONTROL BOAR FOR VEOROX 3 4 FUNCTIONS VS-BCAC-CCC CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCAC CONTROL BOARD FOR VEOROX 3 4 FUNCTIONS VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-SCC-D VS-SCC-D VS-SCC-D VS-SCC-D VS-SCC-D CONNECTION FOR CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THUR CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THIN CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDER HOOK (set of 2) VS-VRN-B-C-CCC THE MACRO CORD REWINDE		
VS-TLCM3-CRD-ECP ROBERTOR FOR PERMITTE CONTROL VS-AMTL MAGNET FOR REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-TLCM3-ECP-FA FRONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOBOX 3 VS-TLCM3-ECP-FA FRONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOBOX 3 VS-TLCM3-ECP-FA FRONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOBOX 3 VS-BCAM REMOVED REAL BATTERY PACK WITH 2 Internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING F3-81ZIN SET OF 2 INTERNAL LITHIUM BATTERY SA/ 22V VS-BCAM-L LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-K-CR 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM CONNECTION RIT WITH FUSES FOR BATTERY PACK VS-BCAM VS-BCAM-K-CC CONNECTION RIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP INTERNAL DELAY FUSE SEX 20-DAL 250 v (set of 5) VS-BCAM-CR BATTERY PACK COMPLETE CASING VS-BCAM-CR BATTERY PACK COMPLETE CASING VS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCAS-CC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCAS-CC-ECP CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCAS-CC-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCAS-BA CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BCAB-BA CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC CAND VS-BCC-CCC-ECP VS-BCAB-BA CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC CAND VS-BCC-CCC-ECP VS-BCAB-BA CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC CAND VS-BCC-CCC-ECP VS-BCAB-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-VEN-BC-CA-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 FUNCTIONS VS-VEN-BC-CA-BA CONTROL BOARD WITH BOARD FOR VEOBOX 3 SECRED (all models) VS-VEN-BC-CA-BA CONTROL BOARD WITH BOARD FOR VEOBOX 3 SECRED (all models) VS-VEN-BC-CA-BA CONTROL BOARD WITH BOARD FOR VEOBOX 3 SECRED (all models) VS-VEN-BC-CA-BA CONTROL BOARD WITH BOARD FOR VEOBOX 3 SECRED (all models) VS-VEN-BC-CA-BA CONTROL BOARD VS-VEN-BC-CA-BA CONTROL BOARD VS-VEN-BC-CA-BA CONTR		
VS-SATTL MAGNET FOR REMOTE CONTROL VS-CRTL REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-CRTL REMOTE CONTROL HOOK VS-BCAM REMOVABLE BATTERY PACK (with 2 internal batteries 5A/12V) WITH LOAD DISPLAY AND BALANCING FS-BTZIN SET OF 2 INTERNAL BATTERY PACK (with 2 internal batteries 5A/12V) WITH LOAD DISPLAY AND BALANCING FS-BTZIN SET OF 2 INTERNAL BATTERIES SA/12V SAT-II INTERNAL LITHIUM BATTERY SA / ZAV VS-BCAM-KCRT SECURIOR OF A STEWN AND AND AND AND AND AND AND AND AND AN		
VS-CRT. REMOTE CONTROL HOOK VS-TICM3-ECP-FA FRONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOBOX 3 VS-EGAM REMOVABLE BATTERY PACK (With 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING F3-BT2IN SET OF 2 INTERNAL LITHIUM BATTERY SA/ 24V VS-BCAM-LI LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-KCRT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP VS-SCAM-LOR INTERNAL DELAY FUSE SX2-DOAMA (set of 5) VS-BCAM-ACRC BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM OU VS-BCAM-SMP VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAS-BCC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-CC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-CC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-CC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCAS-BA CONDECTION KIT WITH DISES FOR CONTROL BOARD VS-BCC-CCC-ECP VS-BAUR CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC-ECP VS-BAUR CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC-ECP VS-SCRD POWER CORD VS-VRN-LO-CAR POWER CORD POWER CORD VS-VRN-LO-CAR 1 DOONO LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-LO-CAR VS-VRN-LO-CAR 1 DOONO LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-LO-CAR 1 DOONO LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-LO-CAR 2 DOON OPENING BASE LEGS GREY ACTUATOR WITH EAD SCREED VS-VRN-LO-CAR 3 DOON OPENING BASE LEGS GREY ACTUATOR WITH CARD SCREED VS-VRN-LO-CARD 3 DOON OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-LO-CARD 3 DOON OPENING BASE LEGS GREY ACTUATOR BASE SCREED 3 DOON OPENING BASE LEGS GREY ACTUATOR CORD		
VS-TLCM3-ECP-FA RONT LABEL FOR REMOTE CONTROL 4 FUNCTIONS FOR VEOBOX 3 KS-BCAM REMOVABLE BATTERY PACK (with 2 internal batteries SA/12V) WITH LOAD DISPLAY AND BALANCING F3-BTZIN SET OF 2 INTERNAL BATTERIES SA/12V VS-BCAM-LI INTERNAL LITHIUM BATTERY SA / 24V UTHIUM BATTERY PACK WITH DISPLAY VS-BCAM-KCC CONNECTION KT WITH FUSES FOR BATTERY PACK VS-BCAM UNS-BCAM-KCCC CONNECTION KT WITH FUSES FOR BATTERY PACK VS-BCAM UNS-SCAM-ACR INTERNAL DELAY FUSE SX20-200MA (set of 5) FUSE-S-20-1A INTERNAL DELAY FUSE SX20-200MA (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAS-ECP CONTROL BOX FOR SY EVENDS X 3 F FUNCTIONS VS-BCAS-EC		
NS-BCAM REMOVABLE BATTERY PACK (with 2 internal batteries 5A/12V) WITH LOAD DISPLAY AND BALANCING P3-BT2IN SET OF 2 INTERNAL BATTERIES 5A/12V SECAM-LI INTERNAL LITHHUM BATTERY SA/ 24V VS-BCAM-LI LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-LC 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRT 3 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRT 4 ELECTRONIC CONNECTION IX TWITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP FUS-5-20-200MA INTERNAL DELAY FUSE 5X 20-1A 250 v (set of 5) VS-BCAM-FAC BATTERY PACK COMPLETE CASING VS-BCAM-FAC BATTERY PACK COMPLETE CASING VS-BCAM-FAC BATTERY PACK HOOK FASTENING VS-BCAM-FAC BATTERY PACK HOOK FASTENING VS-BCAS-CC-C-C-C CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-CCC-C-C CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-CCC-C-C-C CONTROL BOARD FOR VEOBOX 3 5 FUNCTIONS VS-BCC3-CCC-C-C-C CONTROL BOARD FOR VEOBOX 3 6 FUNCTIONS VS-BCC3-CCC-C-C-C-C CONTROL BOARD FOR VEOBOX 3 6 FUNCTIONS VS-BCC3-CCC-C-C-C-C-C-C-C-C-C-C-C-C-C-C-C-		
F3-BT2IN SET OF 2 INTERNAL BATTERIES SA/12V BAT-LI INTERNAL LITHIUM BATTERY SA / 24V VS-BCAM-LI LITHIUM BATTERY SA / 24V VS-BCAM-LY VS-BCAM-KCRT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM VS-BCAM-KCRC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP FUS-S-20-200MA INTERNAL DELAY FUSE SX20-200MA (set of 5) FUS-S-20-1A INTERNAL DELAY FUSE SX20-200MA (set of 5) FUS-S-20-1A INTERNAL DELAY FUSE SX20-200MA (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-FAE BATTERY PACK HOOK FASTENING VS-BCAM-FAE BATTERY PACK HOOK FASTENING VS-BCAS-CCC-CC-CC CONTROL BOARD VERD BOARD VERD SAVE A FUNCTIONS VS-BCC3-ECP CONTROL BOARD VERD BOARD VERD SAVE A FUNCTIONS VS-BCC3-ECP CONTROL BOARD WITH DISPLAY FOR VERD SAVE SECC-CCC AND VS-BCC-CCC-ECP VS-BCAM-FAE SAVE SCC3-BAC COMPLETE EMERGENCY STOP BUTTON VS-VS-BCAM-FAE POWER CORD VS-VS-BCAM-FAE POWER CORD REWINDER HOOK (set of 2) VS-VS-BCAM-FAE POWER CORD VS-VS-BCAM-FAE POWER CORD REWINDER HOOK (set of 2) VS-VS-BCAM-FAE POWER CORD REWIN		
BAT-LI NTERNAL LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-MCH LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-MCFC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM VS-BCAM-KCFC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP VS-BCAM-KCFC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP VS-BCAM-CCC LIVES-5-20-1A INTERNAL DELAY FUSE S x 20-1A 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CCR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CCR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CCR BATTERY PACK BORD FOR VEODOX 3 4 FUNCTIONS VS-BCC3-ECC CONTROL BOAD FOR VEODOX 3 4 FUNCTIONS VS-BCC3-ECC CONTROL BOAD FOR VEODOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOAD FOR VEODOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOAD FOR VEODOX 3 5 FUNCTIONS VS-BCC3-BA CONTROL BOAD FOR VEODOX 3 5 FUNCTIONS VS-BCC3-BA CONTROL BOAD FOR VEODOX 3 7 FUNCTIONS VS-BCC3-BCC3-BCC3-BCC3-BCC3-BCC3-BCC3-BCC	-	
VS-BCAM-LI LITHIUM BATTERY PACK WITH DISPLAY VS-BCAM-KCRT S-ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP FUS-5-20-200MA INTERNAL DELAY FUSE 5 x 20-1a 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAS-C-CCC CONTROL BOARD FOR VS-BCAM-CAR SS-BCAS-C-CC CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-CCCC CONTROL BOARD FOR VS-BCAM-CAR VS-BCAS-C-CD CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-CCP VS-BCAB COMPLETE EMERGENCY STOP BUTTON VS-BCAB VS-BCAB COMPLETE EMERGENCY STOP BUTTON VS-SCRD VS-SCRD POWER CORD VS-VS-RL POWER CORD REWINDER HOOK (set of 2) VSVSNN-FSNIO 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VS-NN-C-CT VS-VS-NN-C-CT 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VS-NN-C-CR 10000N LIFTING ACTUATOR DASS SCREED (all models) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-LO-CR 10000N LIFTING ACTUATOR COMPLETE CASING (all models)		· · · · · · · · · · · · · · · · · · ·
VS-BCAM-KCRT 2 ELECTRONIC BOARDS SET (display and balancing) FOR BATTERY PACK VS-BCAM VS-BCAM-KCRC CONNECTION RIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP FUS-5-20-200MA INTERNAL DELAY FUSE S x20-1A 250 v (set of 5) FUS-5-20-1A INTERNAL DELAY FUSE S x20-1A 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CAR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCAS-CCC-ECP CONTROL BOX VEOBOX 3 4 FUNCTIONS VS-BCC3-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCAS-CCC-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCAS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCAB CONTROL BOARD FOR VEOBOX 3 5 FUNCTIONS VS-BCAS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCAB CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD FUNINDER HOOK (set of 2) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR SSTEM 2 RED BUTTONS SET (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR CORD (all models)		
VS-BCAM-KCFC CONNECTION KIT WITH FUSES FOR BATTERY PACK VS-BCAM OU VS-BCAM-SMP FUS-5-20-200MA INTERNAL DELAY FUSE S x 20-1A 25 0 v (set of 5) VS-BCS-20-1A INTERNAL DELAY FUSE S x 20-1A 25 0 v (set of 5) VS-BCAM-CR BATTERY PACK COMPLETE CASING VS-BCAM-FAE BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAS-CC-CC-CC CONTROL BOX YE OBOX 3 4 FUNCTIONS VS-BCC3-CCC-CCP CONTROL BOX DEVENDOS 3 4 FUNCTIONS VS-BCC3-CCC-CCP CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-CCC-CCP CONNECTION KIT WITH FUSE S FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMBREGENCY STOP BUTTON VS-SCNF CONNECTION KIT WITH FUSE S TOR CONTROL BOARD VS-BCC-CCC CAND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMBREGENCY STOP BUTTON VS-SCNF VS-BCAB-CR VS-VS-CD POWER CORD VS-VS-CD VS-VS-CD POWER CORD VS-VS-CD VS-VS-CD POWER CORD VS-VS-CD VS-VS-CD CONTROL BOX POWER CORD INPUT PLUG VS-VS-CD VS-VS-CD POWER CORD VS-VS-CD POWER CORD VS-VS-CD VS-VS-CD CONTROL BOX TOWN THE MERGENCY LOWERING SYSTEM (all models) VS-VS-VS-CD VS-VS-VS-CD VS-VS-VS-CD VS-VS-VS-CD COMPLETE CONTINUED BASE SCREED (all models) VS-VS-VS-CD VS-VS-CD COMPLETE CONTINUED EMBREGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VS-VS-VS-CD COMPLETE CONTINUED EMBREGENCY LOWERING SYSTEM FOR ACTUATOR (all models) VS-VS-VS-CD COMPLETE CONTINUED EMBREGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VS-VS-CD VS-VS-CD SOON OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VS-CS-CC-CC-CC SOON OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VS-CS-CC-CC-CC-CC-CC-CC-CC-CC-CC-CC-CC-CC		
FUS-5-20-200MA INTERNAL DELAY FUSE SX20-200MA (set of 5) FUS-5-20-1A INTERNAL DELAY FUSE SX 20-1A 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-FAE BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-FAE BATTERY PACK HOOK FASTENING VS-BCAM-CAR BATTERY PACK HOOK FASTENING VS-BCAM-CAR VS-BCAS-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-ECP CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-ECP CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC4-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCAB-CACC-CCC-CCP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-SECH CONTROL BOX POWER CORD INPUT PLUG VS-SECH VS-SECH CONTROL BOX POWER CORD VS-SECH VS-VS-BCAB-CACC-CCC-CCC-CCC-CCC-CCC-CCC-CCC-C	-	
FUS-5-20-1A INTERNAL DELAY FUSE 5 x 20-1A 250 v (set of 5) VS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-FAE BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CR BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCCA-ECP CONTROL BOX VEOBOX 3 4 FUNCTIONS VS-BCC3-ECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCB-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-BCH VS-VEND VS-VE		
NS-BCAM-CAR BATTERY PACK COMPLETE CASING VS-BCAM-FAE BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCCAS-CC CONTROL BOAV VEOBOX 3 4 FUNCTIONS VS-BCC3-CC CONTROL BOAND WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-CC CONTROL BOAND WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-CC CONTROL BOAND WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOAND WITH FUSES FOR CONTROL BOAND VS-BCC-CC AND VS-BCC-CCC-ECP VS-BCB COMPLETE EMERGENCY STOP BUTTON VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-VERL POWER CORD REWINDER HOOK (set of 2) VS-VRN-FSM10 10000N LIFTING ACTUATOR LIFTING STROKE 299mm VS-VRN-FSM10 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-BOR EMERGENCY LOWERING SYSTEM A ZERD BUTTONS SET (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR RED SCREED VS-VRN-ECP3-CENB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CENB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CENB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CENB 3000N OPENING BASE LEGS GREY ACTUATOR CORD	-	· · ·
VS-BCAM-FAE BATTERY PACK ADHESIVE FRONTAGE DISPLAY FOR VS-BCAM VS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCC3-ECP CONTROL BOX VEOBOX 3.4 FUNCTIONS VS-BCC3-ECP CONTROL BOARD FOR VEOBOX 3.4 FUNCTIONS VS-BCC3-ECC-ECP CONTROL BOARD FOR VEOBOX 3.4 FUNCTIONS VS-BCC3-ECC-ECP CONTROL BOARD WITH DISPLAY FOR VEOBOX 3.2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD VS-VS-BCH DOWN LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-HSM10 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-HO-CEMB 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-HO-CAR 10000N LIFTING ACTUATOR COMPLETE CASING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-HO-CAR 10000N LIFTING ACTUATOR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR RAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR CORD		, ,
NS-BCAM-CR BATTERY PACK HOOK FASTENING VS-BCC3-ECP CONTROL BOX YEOBOX 3 4 FUNCTIONS VS-BCC3-ECC-CC-CCC-CCC CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCAM-CR CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD VS-FRL POWER CORD REWINDER HOOK (set of 2) VS-VRN-10-CH HEAD SCREED FOR ACTUATOR KITHING STROKE 290mm VS-VRN-10-CH HEAD SCREED FOR ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR CORD (all models)	-	
VS-BCC3-ECP CONTROL BOAX PEOBOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-KCNF CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-CRD POWER CORD VS-VEN-LOPE POWER CORD REWINDER HOOK (set of 2) VS-VRN-15M10 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-10-CEMB 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING FOR ACTUATOR (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models)		
VS-BCC3-CC-CECP CONTROL BOARD FOR VEOBOX 3 4 FUNCTIONS VS-BCC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-KCNF CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD VS-VENL POWER CORD VS-VENL POWER CORD VS-VENL POWER CORD VS-VENL-GENL POWER CORD REWINDER HOOK (set of 2) VS-VENL-FINI 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VENL-FINI 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VENL-O-CAR 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VENL-O-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VENL-D-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (without the screed) VS-VENL-D-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VENL-ECP3-CENL 10000N DPENING BASE LEGS GREY ACTUATOR VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VENL-ECP3-CENL 10000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-ECC3-BA CONTROL BOARD WITH DISPLAY FOR VEOBOX 3 2 FUNCTIONS VS-KCNF CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD REWINDER HOOK (set of 2) VS-VRN-FSM10 JO00ON LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-FSM10 J000ON LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB J000ON LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB J000ON LIFTING ACTUATOR SASE SCREED (all models) VS-VRN-10-CAR J000ON LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR J000ON LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR J000ON LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR J000ON LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-10-CAR J000ON LIFTING ACTUATOR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD J000ON LIFTING ACTUATOR CORD (all models) VS-VRN-10-CRD J000ON LIFTING BASE LEGS GREY ACTUATOR WITHOUT RAD SCREED VS-VRN-10-CRD J000ON OPENING BASE LEGS GREY ACTUATOR CAD SCREED VS-VRN-10-CRD J000ON OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-10-CRD J000ON OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-10-CRD J000ON OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-10-CRD J000ON OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-KCNF CONNECTION KIT WITH FUSES FOR CONTROL BOARD VS-BCC-CCC AND VS-BCC-CCC-ECP VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD BUTTON VS-CRD POWER CORD VS-CRD POWER CORD REWINDER HOOK (set of 2) VS-VRN-10-CAT 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-10-CHT HEAD SCREED FOR ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR BASE SCREED [all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-10-CARD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CARD 10000N LIFTING BASE LEGS GREY ACTUATOR WITH FAD SCREED VS-VRN-ECP3-CARD 3000N OPENING BASE LEGS GREY ACTUATOR READ SCREED VS-VRN-ECP3-CARD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CARD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-BAUR COMPLETE EMERGENCY STOP BUTTON VS-BCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD REWINDER HOOK (set of 2) VS-VRN-FSM10 1000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-FSM10 1000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 1000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 1000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR 1000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-HO-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CDD 1000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CP3-CMB 3000N OPENING BASE LEGS GREY ACTUATOR RASE SCREED VS-VRN-10-G3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-ERCH CONTROL BOX POWER CORD INPUT PLUG VS-CRD POWER CORD VS-ERL POWER CORD POWER		
VS-CRD POWER CORD VS-ERL POWER CORD REWINDER HOOK (set of 2) VS-VRN-ENL 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-CHT HEAD SCREED FOR ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 1000N LIFTING ACTUATOR WERRING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DM-CAR 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR RAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR RAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-FRL POWER CORD REWINDER HOOK (set of 2) VSVRN-FSM10 10000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-CHT HEAD SCREED FOR ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR WITHOUT ACTUATOR LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VSVRN-FSM10 1000N LIFTING ACTUATOR LIFTING STROKE 290mm VS-VRN-10-CEMB 1000N LIFTING ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 1000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 1000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-HO-CAR 2000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 2000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 2000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-DM-CAR 2000N LIFTING ACTUATOR COMPLETE COMPLINE SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-LO-CRD 1000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR WITHOUT CORD 1000N OPENING BASE LEGS GREY ACTUATOR HAS SCREED VS-VRN-ECP3-CRN 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRN 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-VRN-CHT HEAD SCREED FOR ACTUATOR WITH EMERGENCY LOWERING SYSTEM (all models) VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-BOPA 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-BPR EMERGENCY LOWERING SYSTEM 2 RED BUTTONS SET (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DMC COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR CORD		
VS-VRN-10-CEMB 10000N LIFTING ACTUATOR BASE SCREED (all models) VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-MEDR EMERGENCY LOWERING SYSTEM 2 RED BUTTONS SET (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CTM 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-VRN-10-CAR 10000N LIFTING ACTUATOR COMPLETE CASING (all models) VS-VRN-HABPR EMERGENCY LOWERING SYSTEM 2 RED BUTTONS SET (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DMC COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CTM 3000N OPENING BASE LEGS GREY ACTUATOR RASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED		
VS-VRN-KBPR EMERGENCY LOWERING SYSTEM 2 RED BUTTONS SET (all models) VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-10-CRD 3000N OPENING BASE LEGS GREY ACTUATOR (BUTTON CORD CORD CORD CORD CORD CORD CORD CORD		
VS-VRN-DM-CAR COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM CASING FOR ACTUATOR (all models) VS-VRN-DMC COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VS-VRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR DASE SCREED		
VS-VRN-DIMC COMPLETE CONTINUED EMERGENCY LOWERING SYSTEM FOR ACTUATOR (without the screed) VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VSVRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD	-	` '
VS-VRN-10-CRD 10000N LIFTING ACTUATOR CORD (all models) VSVRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CENB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VS-VRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD		
VSVRN-ECP3 3000N OPENING BASE LEGS GREY ACTUATOR VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VSVRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD	VS-VRN-DMC	
VS-VRN-ECP3-CHT 3000N OPENING BASE LEGS GREY ACTUATOR HEAD SCREED VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VSVRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD	VS-VRN-10-CRD	
VS-VRN-ECP3-CEMB 3000N OPENING BASE LEGS GREY ACTUATOR BASE SCREED VSVRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD	VSVRN-ECP3	
VSVRN-ECP3-CRD 3000N OPENING BASE LEGS GREY ACTUATOR CORD	VS-VRN-ECP3-CHT	
VS-CMB WALL CHARGER FOR BATTERY PACK	VSVRN-ECP3-CRD	
	VS-CMB	WALL CHARGER FOR BATTERY PACK

Cleaning & Maintenance

BEFORE ANY HANDLING:

- Disconnect the AC power cord.
- Check that all electrical components are connected to each other.
- Clean electrical enclosures of the actuators and of the handsets, if they have been soiled by body fluids, especially urine.

OBJECTIVE:

- Repair the patient lift and prevent the transmission of germs from one patient to another.
- Remove any organic soil by mechanical action (cleansing) or chemical action (disinfection).

CLEANING PROCESS:

- Clean the surfaces with a wet cloth by using an apropriate detergent.
- A regular cleaning is recommanded.

WARNING:

- The detergents used must have a neutral pH.
- Avoid the abrasive products and solvent, they could damage the device surface state.

DAILY MAINTENANCE:

- By means of a product applied on the surface in one operation.
- After the patient's discharge by respecting the following operation:
 Cleaning is carried out by means of a cloth impregnated with a disinfectant solution surface.
- Maintenance by specific service providers after removal of the stand-up lift from the facility:
- Biological cleaning operation
- Steam cleaning of various flat surfaces. Change surfaces regularly when washing to avoid water load. Steam cleaning of inaccessible areas. For tubes, steam use with a microfiber mop. Do not direct steam directly on the electrical boxes.

CAUTION:

 Disinfection of actuators, electrical boxes and handsets with a microfiber cloth impregnated with disinfectant

MONTHLY MAINTENANCE:

- Check that the device does not present any visible damages.
- · Check that no part is missing.
- Check the good functioning of the castors and that no matter prevents their begring.
- Check the good fonctioning of the commands as well as the connections of the remote control and the actuator on the battery.
- Clean the sockets and the commands buttons with a dry cloth, if needed with a wet cloth.
- · Check the good state of the electric cables.

Never clean the patient lift, especially the electrical system, with a high pressure cleaner, water hose or similar because doing so could damage the surfaces and seals, and water could enter.

Motorisation Technicals Characteristics

- Removable battery pack
- Digital display of the autonomy
- Emergency stop
- Electrical security lowering system
- Wall charger (in option)
- Remote control 4 functions
- Conform to Standard EN 60601-1
- DC motor low voltage 24V
- 24V / 120VA power
- Maximum strength: 10000 N
- Electrical opening actuator power: 3000 N
- Lifting stroke: 29 cm
- Electronic protection when overloaded
- Protection class: IIProtections types:Remote control: IP65
- Control box: IP65 - Battery pack: IP65
- Actuator: IP55
 Stop limit switch
- Box in ABS
- Handcontrol with spiral cable, low voltage 24V
- Protection against overloading through thermo-switch
- Loudness: less than 55dB at a distance of 1 meter.
- Electromagnetic compatibility: conforms to EN 60601-1-2

Battery Charging Diagram:





Device

class II

Motorisation Technicals Characteristics

A. LCM DISPLAY

0. Information display

- To view the information registered in the control box, you must press the up and down buttons of the box for 5 seconds.

1. Operating factor

- Definition: It accounts for the actuator (up / down) any breach of the duty cycle = non-respect of the actuator rest.



- It counts the number of times an attempt to lift a person weighing beyond the maximum weight limit is performed. When it occurs, the actuator will stop and an anvil will appear, it will be impossible to continue.



- It counts the number of times an attempt to spread or close the opening legs while they are stuck is performed. When it occurs, the actuator will stop and an anvil will appear, it will be impossible to continue.

4. Incomplete load

- It records all incomplete loads below 24,6V. This corresponds to the number of charges damaging the battery.

5. Time of use

- Definition: It displays the cumulative operating time of the device. Starting from 600,000 seconds of use, a maintenance key is displayed; it is then essential to carry out a complete control of the device.











Troubleshooting Guide

Problem	Origin	Solutions
The product, without patient, does not go down.	Our products need some weight to go down.	Push down on the lifting arm while pushing the lowering button on the remote control.
Mobile parts are too hard, product is difficult to handle.	Mobile parts need to be greased.	Grease the mobile parts.
The actuator does not work but the user can hear a "click" in the control box when the remote control button is pushed.	Batteries are unloaded. The actuator jack is not plugged. The actuator jack is deteriorated. There are damages on the actuator or on the control box.	1 . Load the device. 2 . Plug the actuator jack. 3 . The actuator has to be repaired. 4 . The entire electric system has to be checked.
The actuator does not work and the user does not hear a "click" in the control box when the remote control button is pushed.	1. Emergency button is activated. 2. There is no contact between the battery and the control box. 3. Batteries are unloaded. 4. The remote control jack is not plugged. 5. The remote control jack is deteriorated. 6. There are damages on the remote control or on the control box.	1. Turn the button to unlock the device. 2. Take off the battery and put it back. 3. Check the charging cord. 4. Plug the remote control. 5. Change the remote control. 6. The entire electric system has to be checked.
The actuator stops when lifting.	Batteries are unloaded (sound system + "low battery" written on the screen). The product has been used for too long. The weight lifted is too heavy.	Check the charging cord then load battery. Let the device rest a moment (as a protection for the actuator lifespan). Reduce the weight lifted.
The actuator does not work at all	1 . The control box is broken down. 2 . The remote control is broken down.	The control box has to be changed. The remote control has to be changed.

Warranty

- Article 1: NAUSICAA Médical S.A.S. warrants this product against any defects in manufacturing and assembly of mechanical and electronic components. This warranty is for devices used only in accordance with NAUSICAA Médical S.A.S. terms of use.
- The warranty covers all mechanical and electrical parts, except battery and breakage.

This warranty whose terms of use are defined below is valid for 60 months from the date of first departure from NAUSICAA Médical S.A.S.

- Article 2: The warranty entitles the free labor and the free replacement of defective parts.
- Article 3: The original out-going shipping costs of the device and all associated costs are the responsibility of the distributor. The goods always travel at the risk and the responsibility of the distributor. Under warranty: return costs after intervention will be borne by NAUSICAA Médical S.A.S. Out of warranty: return costs are at the expense of the distributor whether or not he accepts the repair estimate.
- Article 4: The warranty does not apply if the claims are consecutive to:
- accident, misuse or neglect of the unit by the end customer.
- shipping performed without adequate protection.
- alteration or transformation not validated by NAUSICAA Médical S.A.S.
- the impact of external elements (natural disaster, fire, shock, humidity, flood, lightning, ...).
- installation and/or use in a non-compliant way with technical standards and safety (in case the unit would work in a country other than the country of origin); and/or if the electrical power is not suited for the operating voltage of the device.
- a lack of routine maintenance.
- Article 5: The distributor may not invoke the benefit of the warranty:
- if the device serial number has been removed, altered or rendered illegible.
- if the device under warranty has been modified without the approval of NAUSICAA Médical S.A.S.
- Article 6: During the repair of any defective equipment, no loan will be made.
- Article 7: All warranty claims must be exercised through the distributor.
- Article 8 : Sending spare parts under warranty will be made after consultation with the distributor customer service.
- Article 9: Defective parts changed under or out of warranty will be guaranteed for 6 months from the date of repair or sending of the spare parts.
- Article 10: No distributor can unilaterally change the terms of this warranty.



CONTACT

Phone: +33 (0) 466 717 184
Fax: +33 (0) 466 532 305
Email: export@nausicaa-medical.com
Website: www.nausicaa-medical.eu

